



18277 Pasadena Street Suite B-102 • Lake Elsinore, CA 92530 • Phone: 714.550.4971 • Fax: 714.550.4973  
Email: Sales@ComfortFirstProducts.com • Website: [www.comfortfirstproducts.com](http://www.comfortfirstproducts.com)

## ***Control-A-Flow***<sup>®</sup>

Draft Eliminator with Anti-Microbial Filter

**&**

## ***Breathe Easy*** **Air Filtering System**

**CAFF 11480 or CAFF 11480-10 PK**

### **How to Replace the Filter with wire frame sealed inside**

The filter fits into the brackets just below the top of the clips. Note the filters have a tight knitted side and a puffy side. The puffy side should face the diffuser, with the knitted side facing the floor. The frame is pliable, so bend the frame over your knee or chest, putting a ½" to ¾ bow in the center of the frame. (The top of the bow will be facing the ceiling.) Place one filter into the filter bracket of one rail, the filter should line up with the outside edge of the T-bar. On the opposite side use your fingers to flex the wire filter frame towards the floor and other rail simultaneously, allowing the filter to clear the bottom of the rail and fit into the opposite bracket. Repeat for second filter. Push the two filters together so they are centered to the diffuser, with the outside edges resting on the T-Bar.

**IMPORTANT:** The filter frame should snugly fit against the T-bar and little or no air should be passing between the diffuser and the filter, ensuring filter efficiency. Run your fingers along the diffuser and filter to feel if air is flowing between them. You may need to increase the "bow" in the middle if this is not achieved the first time.

To view a short video on installation, go to our web site to the Video tab. Click on the Filter Change out link to view the video.

**Replace Filters every 4 to 6 months!**

**For current pricing or to place an order, go online, call or fax us at:**

**[www.ComfortFirstProducts.com](http://www.ComfortFirstProducts.com)**

**(800) 804-3366 or (714) 550-4971**



18277 Pasadena Street Suite B-102 • Lake Elsinore, CA 92530 • Phone: 714.550.4971 • Fax: 714.550.4973  
Email: [Sales@ComfortFirstProducts.com](mailto:Sales@ComfortFirstProducts.com) • Website: [www.comfortfirstproducts.com](http://www.comfortfirstproducts.com)

**FAX (714) 550-4973**